

**PORSCHE DESIGN**  
COMPUTING

**BOOK ONE**  
**Important Safety and Legal Information**





# Table of Contents

<b>1. Intended Use</b>	<b>5</b>
<b>2. Information About This User's Manual</b>	<b>6</b>
<b>3. Explanation of Safety Symbols and Keywords</b>	<b>7</b>
<b>4. General Safety Information</b>	<b>8</b>
<b>5. Notes and Practical Tips on Operational Safety</b>	<b>17</b>
<b>6. Notes and Practical Tips on Maintenance, Storage, and Transport</b>	<b>23</b>
<b>7. Notes and Practical Tips on Maintenance and Repairs</b>	<b>24</b>
<b>8. Notes on Disposal and Recycling</b>	<b>25</b>
8.1 Notes on disposal	25
8.2 Notes on recycling	26
<b>9. Warranty and Support Information</b>	<b>27</b>
9.1 Warranty information	27
9.2 Customer service information	27

# 1. Intended Use

The PORSCHE DESIGN BOOK ONE is a 2-in-1 Windows 10 Pro laptop that can be used for surfing the Internet, running a number of apps (including the Microsoft Office Suite), gaming, and streaming and viewing music, images, and videos.\*

The 2-in-1 laptop features a special hinge that allows the tablet to be rotated by 360° or to be detached from the keyboard.

Never use the device for anything other than its intended purpose. Malfunctions may otherwise occur. Intended use includes observing all instructions contained in the technical documentation. The manufacturer is not liable for damages resulting from improper use or modification of the device.

Furthermore, the manufacturer shall not be held liable for damage or for loss of data or any subsequent damage caused as a result.

The manufacturer shall reserve the right to constantly further develop the product. Changes may be made without any direct reference to them in the user's manual. As a result, the information contained in the user's manual does not need to reflect the current technical design.

Unauthorized modifications to the device (particularly installing external firmware not approved by the manufacturer or modifications to the device hardware) will invalidate the warranty.

\* Not all of the applications you will need are pre-installed at the factory. You can download those apps from the Microsoft Store. Some apps must be purchased.

## **2. Information About This User's Manual**

The online user's manual, the enclosed Quick Start Guide, and the companion brochure "Important Safety and Legal Information" are an integral part of the product.

You can access the online user's manual at [www.porsche-design-computing.com](http://www.porsche-design-computing.com)

Please read all three documents carefully before you turn on your device. They contain important information in regard to safety, use, and disposal of the device.

Please keep these documents in a safe place and pass them on in full to the new owner if the device changes hands.

Please read the operating and safety instructions in full. This will allow you to work safely with maximum efficiency and to protect the device from potential risks.

### **3. Explanation of Safety Symbols and Keywords**

This booklet uses the following safety symbols and keywords:

#### **WARNING**

Indicates possible danger to life and/or danger of severe, irreversible injuries

#### **CAUTION**

Follow instructions to avoid injuries and material damage

#### ***NOTICE***

Follow instructions to avoid material damage

#### **ADVICE**

Additional information about using the device

## 4. General Safety Information

### WARNING

**Risk of multiple injuries due to reduced physical, sensory, or mental capabilities and/or lack of knowledge or practical experience**

- Children and vulnerable individuals may only use the device under direct supervision.

**Risk of suffocation and severe injuries from accessories and packaging materials**

- Keep accessories and packaging materials out of reach of babies, young children, and pets.
- Do not insert accessories and/or parts of the device into orifices such as your mouth, ears, or eyes.

**Risk of electric shock or electrocution from live components**

- Do not insert objects into the device's ventilation slots.
- Do not open the power adapter.
- Do not touch the power adapter if your hands are wet.
- Do not short out the device and/or charger.

**Risk of electric shock or electrocution and/or fire hazard from unsafe connections**

- Make sure the power cord is not bent, crimped, or damaged in any other way.
- Never use the power cord or plug if they are damaged.



- Only use the included power adapter and only connect it to a suitable and professionally installed power outlet. Please read and observe the specifications on the power adapter's label.
- Do not use power outlets if they are loose.
- If the power adapter is defective, contact customer service.

### **Fire hazard and/or risk of burns from damaged or leaking batteries**

- Do not use or charge the device if the battery is damaged or leaking.
- Avoid skin contact with the device and/or battery if the battery is leaking. Wear protective gloves if it is not possible to avoid touching the device/battery in such cases.
- Immediately wash your hands thoroughly in the event of skin contact with the battery substrate.
- If the battery substrate comes into contact with your eyes, rinse them out with plenty of water and consult a physician immediately.

### **Risk of hearing loss through the use of headsets, earbuds, or headphones**

The device can generate high sound levels when using headsets, earbuds, or headphones. This may result in hearing loss if your ears are exposed to high sound levels over an extended period of time. The higher you set the volume, the more quickly your hearing can be damaged. Hearing loss may occur slowly over time.

- Do not listen to music or other audio files for an extended period of time at high volumes.
- Lower the volume before connecting your headset, earbuds, or headphones.
- When using headsets, earbuds, or headphones, make sure the acoustic emissions do not exceed an A-weighted sound level of 80 dB.
- Always set the volume at the lowest level where you can still clearly hear the audio track being played without causing discomfort.
- Do not increase the volume once you have become accustomed to that sound level.
- Adjusting the default settings for the equalizer can boost the device's volume levels.
- Changing the settings of pre-installed software (for example, the operating system, firmware, drivers) can also increase volume levels.

## **Risk of multiple injuries due to reduced attentiveness**

- Safety is the top priority while driving. For this reason, it is prohibited to use the device while operating a motor vehicle.
- Always be aware of your immediate surroundings to avoid putting yourself or others at risk.
- When using a headset, earbuds, or headphones in public, adjust the volume so that you can still hear noises or sounds in your surroundings. Distractions or being cut off from your surroundings may lead to accidents. It is illegal to use headsets, earbuds, or headphones while operating a motor vehicle in some regions.

## **Risk of interference with other electronic devices that transmit high-frequency signals**

- Switch off the device in safety or security zones where the use of mobile devices is prohibited (e.g., when the plane is taking off or landing, in hospitals, or near medical equipment). Obey the corresponding signs and warnings and strictly observe the instructions contained on them.
- You are allowed to use the device in airplane mode with the permission of the flight crew once the aircraft has taken off. Please note that use of the device may interfere with the plane's electronic navigation systems.
- Refrain from using the device near other electronic devices.

## **Risk of multiple injuries and fire/explosion hazard in potentially explosive atmospheres**

- Operating the device in potentially explosive atmospheres, such as at filling stations, on construction sites, or in chemical plants, is prohibited.
- Switch off the device if you are in areas that contain potentially explosive materials (e.g., gas, fuel, chemicals, particulate matter, grain, dust, or metal powders). Sparks could cause an explosion or fire.
- Obey the corresponding signs and warnings in these areas and strictly observe all instructions contained on them.

### **CAUTION**

#### **Risk of fire or explosion when using non-approved chargers and power adapters**

- Only use the included power adapter or an equivalent power adapter to charge the battery.
- If the power adapter is defective, only exchange it for an equivalent power adapter. Please note the information in the technical specifications of the power adapter in the online user's manual or contact customer service.

## **Risk of multiple injuries from slipping, tripping, or falling**

- Do not expose the device and/or power adapter to vibrations and/or any form of impact.
- Do not drop the device and/or power adapter. Do not use the device/power adapter if it has been dropped and/or is damaged. Have a qualified service technician check the device/power adapter before restarting it.
- Always ensure that the power cord is installed securely.
- Do not allow the power cord to knot or kink.

## **Risk of adverse effects to health in the case of a known predisposition to photosensitivity**

- If members of your family have been known to exhibit manifestations of photosensitivity (e.g., seizures when using similar devices), it is advisable to consult a physician before operating the device.
- Watching videos and/or playing video games with rapid frame rates over an extended period of time may trigger a seizure or lead to fainting. Cease all use of the device if you are feeling unwell and wait an appropriate amount of time before starting to use it again.
- If you are experiencing muscle cramps or feeling disoriented while using the device, cease all use of the device immediately and consult a physician.

- To avoid tiring or straining your eyes, please note the following:
  - Only use the device indoors under suitable lighting conditions and avoid harsh light.
  - Hold the device at an appropriate distance from yourself.
  - Ensure that the display is clean.
  - Adjust the screen's brightness and/or contrast settings to a level that is comfortable for a crisp, clear display.
  - Take regular breaks when using the device.
- Due to the device's high-gloss screen, it is not suitable for use at computer workstations.

**Risk of impairment to the musculoskeletal system and supporting tissue from use over longer periods of time**

- Repetitive movements (e.g., use of keyboard/touch screen or playing games for an extended period of time) may result in pain in the hands, arms, shoulders, neck and shoulder region, and in other parts of the body. To avoid tiring or straining your musculoskeletal system and supporting tissue, please note the following:
  - Always assume a relaxed posture when using the device.
  - Change your position regularly and take frequent breaks to move around.

- Press lightly when typing.
- Take regular breaks.
- If you are experiencing discomfort similar to that indicated above while using the device, cease all use of the device immediately and consult a physician.
- Do not rest the device on your lap or other parts of your body when in use. The device may heat up, resulting in discomfort or injury (e.g., minor burns).

## ***NOTICE***

**To avoid potential malfunctions and/or damage to the device caused by environmental factors, please note the following:**

- The recommended humidity for operating, charging, and storing the device is between 30 and 70 percent.
- The recommended ambient temperature for operating, charging, and storing the device is between 5°C and 30°C. Temperatures above or below this may adversely affect the charging capacity and service life of the device and battery and cause damage to the device.
- Protect the device from rapid temperature fluctuations. Condensation from humidity can damage the device and may result in danger to the user.
- Shield the device from direct sunlight (e.g., in the car) and do not store it near a heat source to prevent the display and device from malfunctioning and avoid the risk of the battery exploding.

- Keep the device away from open flames such as candles, fireplaces, and campfires to avoid the risk of the battery exploding.
- Do not expose your device to rain or to dripping or splashing water.
- Do not use the device outdoors during a storm.
- Should the device become wet, turn it off immediately. Ensure that the device and/or the power adapter are checked by a qualified person before using it again.
- Use the device in a dust-free environment.
- Magnetic fields may cause the device to malfunction and/or the battery to discharge.

**To prevent possible damage to your device:**

- Do not charge your device on standard USB ports such as those found on desktop or laptop computers.
- Take care to wind the cord loosely.
- Moisture, dense smoke, and fumes may lead to malfunctions and/or damage the device's housing.

 **ADVICE**

The storage capacity indicated on the packaging and in the technical specifications refers to the total storage capacity of your device. The storage capacity of your device as indicated by the operating system may differ from the specified storage capacity, as a portion of the total storage is also used by the operating system and system applications.



## 5. Notes and Practical Tips on Operational Safety

### WARNING

#### **Risk of explosion and/or fire if the device becomes hot and/or due to improper handling and use**

- Never throw the device into a fire, for example, in order to dispose of it.
- Do not cover the device or power adapter during operation or while charging the device to prevent overheating.
- Always ensure that all ventilation slots and openings on the device are free and unobstructed. They are used to cool the device. Do not cover these openings by placing the device on unsuitable surfaces, such as on a bed, couch, or carpet. By allowing optimum heat transfer, it is possible to reduce the risk of fire and ensure that the device operates dependably.
- Do not place the device on or in appliances or objects that produce heat, such as microwaves or radiators.
- The battery may catch fire if the charging voltage is too high.
- If smoke develops or if there are any strange sounds or smells coming from the device, stop working with the device immediately and unplug the power adapter from the power socket if necessary. Disconnect all peripherals connected to the device and switch off the device (take care due to the heat). Ensure that the device and/or the power adapter are checked by a qualified person before using it again.

## CAUTION

### **Risk of injury and/or damage to the device, battery, and/or charging cable due to improper use**

- Do not place the device on slanted or unstable work surfaces or stands.
- Do not rest the device against your vehicle's airbag or the airbag's triggering areas. Injury may result when the airbag deploys due to the powerful force behind it.
- To prevent short circuits or corrosion, do not allow the ports or connectors on the device, charger, and keyboard to come in contact with conductive materials like fluids, dust, metal, or graphite. This also applies to the gold contacts on memory cards.
- If you break the glass panel, do not touch the glass fragments. Do not try to remove the glass fragments from the device. Do not use the device again until the display has been replaced by a qualified service technician.
- Please note the following in order to protect the display's glass panel from breakage:
  - Do not operate the display using pointed objects.
  - Do not exert excessive pressure on the display.

## ***NOTICE***

### **Risk of data loss, malfunctions, and damage to the device due to electrical surges and/or improper handling of accessories**

- Always connect the correct end of the cable to the device.
- Always insert the microSD-HC/XC or similar cards into the designated slot facing the right direction. Check the contacts to ensure you are inserting the card correctly.
- If you use force to insert a card or connect a cable, or insert or connect them incorrectly, this may damage parts of the device and void the warranty.
- If you remove a memory card from the device while data is being transferred (read or written), this may result in the loss of data and/or damage the card or device.

### **Risk of data loss, malfunctions, and damage to the device resulting from viruses, malware, and the careless handling of programs and data**

- Do not install any firmware on the device unless it is provided by the manufacturer. Installing third-party firmware (for example, custom ROMs) may result in the loss of data and cause damage and malfunctions in the device. This may also void the device's warranty.
- Do not make any changes to the operating system or registry.

- Do not delete unknown files.
- Do not change the names of files or folders that you did not create yourself.
- Accessing network resources makes the device vulnerable to hackers, spyware, computer viruses, and other harmful activities that could damage the device, the software, or your data. Here are a few tips on how to prevent the loss of data and damage to the device:
  - Install antivirus software and update it regularly.
  - Install a firewall and update it regularly.
  - Install anti-spyware software and update it regularly.
  - Do not install unknown apps or apps from unknown sources.
  - Use antivirus software to scan apps you recently downloaded before opening them.
  - Only use trusted websites.
  - Use safe passwords and change them regularly.
  - Disable wireless connections like WiFi or Bluetooth when not in use.
- Protect your data by regularly backing it up; if possible, on multiple storage devices.
- When downloading apps, check and consider the access rights you will be required to provide with regards to access to your personal data.
- Check your accounts regularly for misuse.

- If you will no longer be using the device, back up your important data and reset the device to its factory settings.
- If you lose the device, immediately change any login data to protect your personal data.

### **Risk of damage to the device, battery, and/or charging cable due to improper use**

- Overcharging or total discharge of the battery may shorten its lifespan.
- The battery must be ‘trained.’ A battery will not reach full capacity until after several charging cycles.
- Do not place heavy objects of any kind on the charging cable or device.
- Do not use the display to transport objects.

**i** **ADVICE**

- The device will typically become warm during charging. This will not adversely affect the lifespan or performance of the device.
- Unplug the charger from the outlet and the device itself after charging to keep the built-in battery from discharging more quickly.
- Do not use USB cables over 3 m in length to prevent possible disruptions while transferring data.
- Exposing your device to electrostatic discharge may interrupt the transfer of data between your device and a connected USB device (e.g., USB memory stick), disrupt the WiFi connection, or cause the device to malfunction. If this happens, disconnect any USB devices that are connected, restart your device, and reconnect to the WiFi network if necessary.

## **6. Notes and Practical Tips on Maintenance, Storage, and Transport**

### ***NOTICE***

#### **Risk of damage to the device and/or battery if the instructions are not observed**

- Never clean the surface of the device with solvents, paint thinners, cleaning agents, or other chemical products. This may cause the surface of the device's housing to become discolored, damaged, or destroyed.
- Instead, use a soft, dry cloth or a soft paintbrush.
- If the display is extremely dirty, we recommend using a special screen cleaner to clean it.
- When the device is not in use for an extended period of time, recharge the battery at regular intervals in order to prevent reduced performance and total discharge. Total discharge may permanently damage the battery.
- When not in use, keep the device in a dry, clean, dust-free place protected from light.
- Ensure a constant temperature wherever possible.
- Switch off the device before transporting it.
- When transporting the device, ensure that you use soft, stable packaging that protects the device from mechanical stress, moisture, dust, and light.

## **7. Notes and Practical Tips on Maintenance and Repairs**

### **⚠ WARNING**

#### **Risk of electric shock and electrocution from live components**

- Never open the casing of the device and/or the power adapter. No parts inside the device require maintenance or cleaning.
- The battery in the device should not be removed by the user. Do not disassemble the battery, place objects into it, or handle liquids near it. The battery could catch fire or explode.
- It is prohibited to repair or modify the device and/or power adapter. Failure to comply with these instructions may void the warranty.
- The device should only be serviced and repaired by a qualified service technician. Contact customer service where repairs or servicing are required.



## 8. Notes on Disposal and Recycling

### 8.1 Notes on disposal



This symbol on the device and in the accompanying documentation indicates that the device must be disposed of separately from normal household waste. This device (and the battery it uses) contain valuable raw materials such as rare earths and precious metals as well as components that are harmful to the environment and/or human health if not disposed of properly. By properly disposing of used appliances and batteries, you are making a vital contribution to conserving resources, minimizing pollution, and protecting the environment as best as possible.

Under European law you are required as a consumer to dispose of electronic waste and used batteries/appliances separately. As per national laws and provisions and/or EU Directives 2002/96/EC and 2006/66/EC, electronic waste and used batteries must be taken to the appropriate collection centers.

Please note: Improper disposal of used appliances and batteries is a criminal offense in certain countries.

## 8.2 Notes on recycling



Your device and its sales packaging consist of valuable raw materials, which must be recycled in the interest of environmental protection. Contact your city or municipal authority for information on the correct method of disposal.



### **Information on disposal in non-EU countries**

These symbols only apply in the European Union. Information on proper disposal of these devices is available from your local competent authority or from the retailer.

## **9. Warranty and Support Information**

### **9.1 Warranty information**

The warranty is valid for 24 months from the purchase date. There is no warranty beyond this.

Unauthorized modifications to the device (particularly installing external firmware not approved by the manufacturer or modifications to the device hardware) will invalidate the warranty.

### **9.2 Customer service information**

If your device is faulty or defective, please feel free to contact customer service at [www.porsche-design-computing.com](http://www.porsche-design-computing.com) and arrange to be called back at a time that works best for you.

In order for us to provide you with fast, optimum support, please keep all information necessary to identify the device (serial number, purchase date/location) ready at hand. If at all possible, make note of any error messages that are related to the issue and have your device switched on before contacting customer service.

Go to [www.porsche-design-computing.com](http://www.porsche-design-computing.com) and open the "Support" section for the latest news and information, useful tips, and available drivers and downloads.

You will also find full and complete information about the warranty for your 2-in-1 laptop.





Copyright © 2017. All rights reserved. Some product or company names mentioned elsewhere may be brand names or trade names of the respective proprietor.

Important Safety and Legal Information  
SI-PD-V2-10-US-EN-170223

This document contains the technical specifications and product information current at the time of printing. All information found in this document, including URLs and links to websites, is subject to change without prior notification.

Individual content may vary from region to region or based on the device specifications/software from your device.

Please note the proprietary notice pursuant to DIN ISO 16016. Copyright law prohibits the copying, utilization, and distribution of the content of this document (illustrations, reference documents, etc.), as a whole or in part, without the permission of the copyright holder.



